

- 14 Plug in the Conf/TDS cards. Push the latches forward to lock the card in place.
- 15 Faceplate enable the Conf/TDS cards.
- 16 Enable the Conf/TDS cards:

LD 34 to load the program
ENLX x (loop) to enable the Conf/TDS card
******** to exit the program
- 17 Add additional Network cards as required.

The upgrade procedure is complete. The FIJI Ring States should be in Half mode. Verify that phone calls can be made in the new group.

